

NEW EXTERIOR CONCRETE DRIVEWAY WORK



1. Visit the site.

2. Contact Ms. Utility.

3. Mobilize to the site.

4. Remove existing failed driveway.

5. Grade to uniform depth and compact area.

6. Install 6 x 6 #10 wire mesh.

7. Install new 4 inch thick 4000 PSI strength concrete.

8. Place concrete material and bull float the concrete.

9. Install control and expansion joints where and if necessary.

10. Install a light broom finish.

11. Apply seed and straw.

12. Pick up and haul away all project debris.